



## **MK Scarifier Safety Precautions**

1. Make sure guards are in place and in good condition.
2. Gas is extremely flammable, keep away all open flames or sparks to avoid any explosions. Do not fill the fuel tank while the engine is running or hot.
3. Never run engine in a closed building or confined area, be sure there is always proper ventilation so exhaust fumes cannot build up to be dangerous.
4. Never touch electrical wires or components while the motor is running.
5. Before starting the engine, be sure the on/off switch is in the “OFF” position to prevent accidental starting. Place the on/off switch in the OFF position before performing any service operation.
6. Keep hands, feet, hair, and clothing away from all moving parts to prevent injury. Never operate a power tool with shrouds or guards removed.
7. Wear proper personal protection equipment:
  - Safety glasses
  - Respiratory protection
  - Hearing protection



**Tool RENTALS** Ltd.

- proper apparel – no loose clothing, gloves, neckties, rings, bracelets, or other jewelry that might get caught in moving parts. Non-slip footwear is recommended

8. Make sure keys and wrenches are removed from the tool before it is turned on.

9. Keep work area clean.

10. Do not force the tool.

11. NEVER leave tool running unattended – turn power off.

12. Clamps or a vise should be used to hold work whenever practical keeping hands free to operate the tool safer.