



Bobcat Skid Steer Safe Operating

Read and understand operators manual before use

1. Use 3 point contact when entering and exiting the machine.
2. Wear the seat belt and lower seat bar for restraint.
3. Never exceed the machines rated operator capacity.
4. Never use loader as a man lift or elevating device for personnel.
5. If you must work in an enclosed area, make sure there is adequate ventilation as exhaust fumes can be harmful.
6. Never carry riders, keep bystanders away from work area.
7. Always carry bucket or attachments as low as possible. Do not travel or turn with arms up. Load, unload and turn on flat level ground.
8. Never leave the loader with the engine running or with the lift arms up. To park, engage the parking brake and put attachments flat on the ground.
9. Wear proper clothing and use personal protection equipment as required for the job.
10. Call local utilities before you dig: 1-888-258-0808
 - Know the location of underground gas, water and electrical lines.
11. On slopes, keep heavy end uphill and never go across them.
12. Keep hands and feet on controls or footrests. Never lean out the front of the cab with the engine running.